

Resene Membrane Roofing Primer

Resene Membrane Roofing Primer is a specially formulated pre-treatment to upgrade adhesion, both wet and dry, to rubber membrane sheeting materials.

exterior

Typical uses

- Asphalt tennis courts
- Bituminous substrates
- EPDM and butyl rubber membrane sheeting

| | |
|------------------------------|---|
| Vehicle type | Vinyl polymer |
| Pigmentation | Virtually none |
| Finish | Gloss |
| Colour | Slightly milky |
| Dry time (minimum) | 20 minutes |
| Theoretical coverage | 16 sq. metres per litre |
| Dry film thickness | 28 microns at 16 sq. metres per litre |
| Usual no. of coats | 1 |
| Water resistance | Excellent |
| Thinning and clean up | Water; Resene Hot Weather Additive |
| Overcoating | Two coats - Resene Hi-Glo (see Data Sheet D31), Resene X-200 (see Data Sheet D62), Resene Lumbersider (see Data Sheet D34) |
| VOC | c. 2 grams per litre (see Resene VOC Summary) |

Physical properties

Performance

Performance and limitations

1. Rapid dry.
2. Easy application.
3. Excellent wet and dry adhesion.
4. An Environmental Choice approved product.

Limitations

1. Resene Membrane Roofing Primer is not designed to give long-term protection without topcoating. Overcoat within three months.
2. In summer months black roofing membranes can get very hot, leading to very rapid dry times and reduced flow properties. Use Resene Hot Weather Additive to slow drying.
3. Will not isolate bituminous substrata from subsequent solventborne topcoats.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If in doubt contact Resene.



Membrane Roofing Primer

Surface preparation

Ensure surface is clean and free from all contamination and detritus. Brooming with Resene Roof and Metal Wash (see [Data Sheet D88](#)) and water, followed by thorough rinsing with clean water is normally sufficient.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, roller or spray. Rolling tends to create foaming, which is minimised by the use of polyester rollers. One coat only is sufficient.

Precautions

1. Resene Membrane Roofing Primer is slightly acidic.
2. If eyes become contaminated, flood with running water for at least 15 minutes. SEEK MEDICAL AID.



Membrane Roofing
Primer SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 924, Beenleigh, Qld 4207
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.